
J/C(5)
D-15
<6B3>
RIGHT BANK OXYGEN SENSOR (REAR)
RIGHT BANK OXYGEN SENSOR (FRONT)
LEFT BANK OXYGEN SENSOR (FRONT)
RELAY BOX (FUSE F2)
1
2
3
4
5
6
7
8
9
10
11
12
RIGHT BANK OXYGEN SENSOR (REAR)
LEFT BANK OXYGEN SENSOR (REAR)
ENGINE-ECU
RIGHT BANK OXYGEN SENSOR (FRONT)
LEFT BANK OXYGEN SENSOR (FRONT)


·BLIND SPOT WARNING SWITCH
·DRIVE MODE-SELECTOR
·E-CALL SWITCH
·ELECTRIC PARKING BRAKE SWITCH
·HEATED SEAT SWITCH (SECOND)
·HEATED STEERING WHEEL SWITCH
·HILL DESCENT CONTROL SWITCH
·OFF-ROAD MODE SELECTOR
·REAR COOLER CONTROL PANEL
·REAR FAN SWITCH
HEADLAMP MANUAL LEVELLING SWITCH
J/C(3)
·E-CALL SWITCH
·FORWARD COLLISION MITIGATION SYSTEM (FCM) AND ULTRASONIC MISACCELERATION MITIGATION SYSTEM ON/OFF SWITCH
·SONAR SWITCH
·MULTIVISION DISPLAY
·RADIO AND CD PLAYER
·SMARTPHONE LINK DISPLAY AUDIO
·HAZARD INDICATOR ASSEMBLY
·HAZARD WARNING LAMP SWITCH
HEATED SEAT SWITCH (FRONT)
COMBINATION METER (PWM)
ASC OFF SWITCH
REAR DIFFERENTIAL LOCK SWITCH
HEATER CONTROLLER ASSEMBLY
SELECTOR LEVER ASSEMBLY
J/C(6)
D-244
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
J/B (FUSE 7)
BLIND SPOT WARNING SWITCH
HEATED STEERING WHEEL SWITCH
ASC OFF SWITCH
E-CALL SWITCH
FORWARD COLLISION MITIGATION SYSTEM (FCM) AND ULTRASONIC MISACCELERATION MITIGATION SYSTEM ON/OFF SWITCH
HEATED SEAT SWITCH (FRONT)
SONAR SWITCH
HEADLAMP MANUAL LEVELLING SWITCH
·A/C-ECU
·HEATER CONTROLLER ASSEMBLY
REAR DISPLAY UNIT


D-15
1 2 3 4 5 6
7 8 9 10 11 12
D-244
1 2 3 4 5 6 7 8 9 10 11
12 13 14 15 16 17 18 19 20 21 22

HHM00X03BC