7

8

OUTER BUZZER A-34

KEYLESS OPERATION KEY

2 B-W 1. 25B

1 R-W 0. 35BE 4 D-04 29 D-222

2

DRVB

INSIDE TRANSMISSION ANTENNA ASSEMBLY (FRONT) E-25

1 <T> (L) 11 <T>0. 35SB 5

5 <T> (L-W) 10 <T>0. 35G 13

INFP INFG

INSIDE TRANSMISSION ANTENNA ASSEMBLY (REAR) E-07

1 <T> (L-G) 9 <T>0. 35P 7

5 <T> (L-O) 8 <T>0. 35L 15

INRP INRG

KOS& OSS-ECU

UHF RECEIVER

DRRQ 30 0. 35LG 17 D-230 (G-B) 1

ASRQ 47 0. 35GR 17 D-220 (G-B) 1

LOCK/ UNLOCK SWITCH (DRIVER'S SIDE) G-13

LOCK/ UNLOCK SWITCH (PASSENGER'S SIDE) G-16

2 (B) 5 D-231 <F>2B <F>2B

20

2 (B) 5 D-221 <F>2B <F>2B

7

EASP EASG EDRP EDRG

D-223 6 <T>0. 35W 5 D-02 <T> (G) 1

6 <T>0. 35LG 4 <T> (G-W) 5

4 <T>0. 35Y 7 <T> (L-R) 1

12 <T>0. 35BE 6 <T> (L-Y) 5

OUTSIDE TRANSMISSION ANTENNA ASSEMBLY (PASSENGER'S SIDE) E-04

OUTSIDE TRANSMISSION ANTENNA ASSEMBLY (DRIVER'S SIDE) E-13

A-34 MU802661

D-02

D-04

D-220

D-221

E-13

E-25

G-13

G-16

D-222

D-223

D-230

D-231

E-04

E-07

Wire colour code
B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige

HHSM0X02DC