



Valve seat
height

The diagram shows a cross-section of a valve seat. A vertical double-headed arrow on the left indicates the 'Valve seat height', which is the distance from the top of the seat to the bottom of the hole. A horizontal double-headed arrow at the bottom indicates the 'Oversize hole diameter', which is the width of the hole at its widest point. The hole's profile is shown as a smooth curve that tapers towards the bottom. The seat is shown as a hatched rectangular block, and the hole is shown as a curved profile within it.

Oversize hole diameter

AK400380AD