



Valve seat
height

The diagram shows a cross-section of a valve seat. A vertical double-headed arrow on the left indicates the 'Valve seat height'. A horizontal double-headed arrow at the bottom indicates the 'Oversize hole diameter'. The seat is shown as a hatched area on the right, with a curved profile on the left. The top surface is flat, and the bottom surface is curved. The hole is oversized, meaning its diameter is larger than the seat's diameter.

Oversize hole diameter

AK400380AD