

- Manifold absolute pressure sensor
- Intake air temperature sensor
- Engine coolant temperature sensor
- Accelerator pedal position sensor
- Camshaft position sensor
- Crank angle sensor
- Ignition switch-ST
- Detonation sensor

