



Air refresher
assembly

Air refresher assembly

Upwards



Assemble into the heater side
cover in this direction.

ACC02772AB