


Radio and Tape Player or Radio and CD Player Power Supply Circuit



NOTE
 * 1: LHD
 * 2: RHD

Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet