



Purge control solenoid valve

The diagram is a black and white line drawing of an engine compartment. It shows various components including hoses, a solenoid valve, and a canister. Two leader lines with dots at the end point to the 'Purge control solenoid valve' and the 'Canister'. The solenoid valve is located in the center-left area, and the canister is a cylindrical component on the right side of the engine bay.

Canister

**AKB00630AB**