

Ask the customer about the trouble symptom.

CVT fluid check

NG

CVT fluid replacement

OK

Trouble symptom check

Communication with M.U.T.-III is not possible

Read the diagnosis code.

Inspection procedure

Diagnosis code is set

Diagnosis code is not set

Erase the diagnosis code.

Trouble symptom check

Inhibitor and APS check

Road test

Abnormal (Diagnosis code is not set)

Abnormal (Diagnosis code is set)

Normal

Read the diagnosis code again.

Diagnosis code is set.

Diagnosis code is not set.

To diagnosis code chart

To trouble symptom chart

Determine the cause.

Determined

Not determined

Repair

Intermittent malfunction (Refer to GROUP 00 - How to Cope with Intermittent Malfunction)

NG

NG

Check (Road test)

OK

Complete