


Heater unit assembly



**1**  
Rotate the air outlet changeover  
damper lever to the FACE position.

**2**  
Rotate the air outlet changeover  
knob to the FACE position.

Fit the cable into the clip