







INSIDE TRANSMISSION ANTENNA ASSEMBLY (FRONT) (C-116)





INFP INFG

OUTER BUZZER (G-09)




INSIDE TRANSMISSION ANTENNA ASSEMBLY (REAR) (D-13)




INRP INRG


KOS AND OSS-ECU





DRRQ




GTRQ





EASP




EASG





EGTP




EGTG




EDRP




EDRG




(C-11)




(C-12)




(C-116)




(C-124)




(C-131)




(C-132)




(D-07)



(D-13)



(D-18)



(D-21)



(F-11)



(G-04)



(G-07)



(G-09)



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver