



Detonation sensor

The diagram shows a cross-section of an engine block with a detonation sensor installed. The sensor is a cylindrical component with a hexagonal face, mounted on a horizontal surface. A curved arrow indicates a 45-degree angle between the sensor's axis and a vertical reference line. The sensor is secured with a nut and washer. Various other engine components, such as pistons and valves, are visible in the background.

45°

AC807670 AD