


Connector "A"

Connector "C"

ETACS-  
ECU



Connector "B"

Connector "D"

Fuel  
pump  
relay

AK701305AD