



Oxygen sensor  
(rear) connector

This diagram shows a close-up of the rear oxygen sensor connector. A line points from the text label to the connector on the sensor. To the right, a separate diagram shows a 2x2 grid of terminals labeled 1, 2, 3, and 4. A line points from the bottom-right terminal (4) to the connector in the main diagram.

Equipment side  
connector



Oxygen sensor (rear)

This diagram shows the rear oxygen sensor installed in the exhaust manifold. A line points from the text label to the sensor. The sensor is secured with a nut and washer. The exhaust manifold is shown with a textured surface.

AKC00016AB