

KOS/IMMO/Keyless

Special Function

Comm. Test

Item

Comm. Test

Item

Front antenna (indoor)

Front (LH) antenna (outdoor)

Front (RH) antenna (outdoor)

Rear (Left) antenna (indoor)

Rear (Right) antenna (indoor)

Tail gate antenna (outdoor)

OK button

Please select the antenna to test.
Test is started by pressing OK button.

Start the test after putting kos key on the position which communication with selected antenna.



AC509796 AC