


IGNITION SWITCH (IG1) OR OSS-ECU (IG1)











FUSIBLE LINK (2)

ETACS-ECU



- ABS-ECU
- ASC-ECU
- ACC/FCM-ECU
- A/T CONTROL RELAY
- COLUMN SWITCH
- CORNER SENSOR/BACK SENSOR-ECU
- CVT CONTROL RELAY
- EPS-ECU
- HAZARD INDICATOR ASSEMBLY
- HEATED SEAT RELAY
- HEATER CONTROLLER ASSEMBLY (A/C-ECU)
- KOS-ECU
- SELECTOR LEVER ASSEMBLY
- SONAR SWITCH
- STEERING WHEEL SENSOR
- SUNROOF MOTOR ASSEMBLY

NOTE
 *1: VEHICLES WITHOUT KOS
 *2: VEHICLES WITH KOS
 *3: VEHICLES WITH STANDARD METER
 *4: VEHICLES WITH HIGH CONTRAST METER



Wire colour code
 B: Black LG: Light green G: Green L: Blue W: White
 Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey
 R: Red P: Pink V: Violet PU: Purple SI: Silver