



- NOTE
- * : -ABS-ECU
 - ACC/FCM-ECU
 - ASC-ECU
 - A/T CONTROL RELAY
 - COLUMN SWITCH
 - COMBINATION METER
 - CORNER SENSOR/BACK SENSOR-ECU
 - CVT CONTROL RELAY
 - EPS-ECU
 - HAZARD INDICATOR ASSEMBLY
 - HEATED SEAT RELAY
 - HEATER CONTROLLER ASSEMBLY (A/C-ECU)
 - SELECTOR LEVER ASSEMBLY
 - SONAR SWITCH
 - STEERING WHEEL SENSOR
 - SUNROOF MOTOR ASSEMBLY

Wiring diagrams for connectors and fuses:

- C-02** (MU801515): 12-pin connector
- C-03** (MU801515): 12-pin connector
- C-05** (MU801852): 12-pin connector
- C-08** (AMP): 24-pin connector
- C-09** (AMP): 16-pin connector
- C-30** (MU801847): 11-pin connector
- C-113** (MU801885): 32-pin connector
- C-202** (MU801515): 12-pin connector
- C-221** (MU801885): 16-pin connector
- C-222** (MU801515): 22-pin connector
- C-402** (MU801839): 8-pin connector
- C-403** (MU801845): 10-pin connector
- C-412** (MU801325): 2-pin connector
- C-417** (MU801325): 36-pin connector
- F-13** (MU801885): 4-pin fuse
- F-14** (MU801885): 10-pin fuse

Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver