







FUSIBLE LINK (SBF7)

FUSIBLE LINK (SBF5)



IGNITION SWITCH (IG1) OR OSS-ECU (IG1)

FUSIBLE LINK (2)





NOTE
 *1: VEHICLES WITHOUT KOS
 *2: VEHICLES WITH KOS

RELAY BOX
 (PASSENGER
 COMPARTMENT)
 FUSIBLE LINK
 AND FUSE

INPUT SIGNAL
 STOP LAMP
 SWITCH

- ACC/FCM-ECU
- A/T CONTROL RELAY
- COLUMN SWITCH
- CORNER SENSOR/BACK SENSOR-ECU
- CVT CONTROL RELAY
- EPS-ECU
- HAZARD INDICATOR ASSEMBLY
- HEATED SEAT RELAY
- HEATER CONTROLLER ASSEMBLY (A/C-ECU)
- KOS-ECU
- SELECTOR LEVER ASSEMBLY
- SONAR SWITCH
- SUNROOF MOTOR ASSEMBLY



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver