



- NOTE
- *3 : VEHICLES WITHOUT KOS
 - *4 : VEHICLES WITH KOS
 - *5 : VEHICLES WITH AUTO LAMP
 - *6 : ABS-ECU
 - ACC/FCM-ECU
 - ASC-ECU
 - A/T CONTROL RELAY
 - COMBINATION METER
 - CORNER SENSOR/BACK SENSOR-ECU
 - CVT-ECU
 - EPS-ECU
 - HAZARD INDICATOR ASSEMBLY
 - HEATED SEAT RELAY
 - HEATER CONTROLLER ASSEMBLY (A/C-ECU)
 - KOS-ECU
 - PTC HEATER RELAY
 - PRIMARY PULLEY SPEED SENSOR
 - SECONDARY PULLEY SPEED SENSOR
 - SELECTOR LEVER ASSEMBLY
 - SONAR SWITCH
 - STEERING WHEEL SENSOR
 - TURBINE SPEED SENSOR
 - WATER LEVEL SWITCH

