











- NOTE
- *4 : LHD
 - *5 : RHD
 - *6 : 4WD SWITCH
 - ASC OFF SWITCH
 - DOWNLIGHT
 - ELECTRIC TAILGATE SWITCH
 - FCM SWITCH
 - HEADLAMP MANUAL LEVELLING SWITCH
 - HEATED SEAT SWITCH
 - LDW SWITCH
 - MULTIVISION DISPLAY SWITCH
 - METER INFORMATION SWITCH
 - RADIO AND CD PLAYER
 - S-AWC DRIVE
 - MODE-SELECTOR
 - SONAR SWITCH
 - SPARE CONNECTOR (FOR AUDIO)
 - *7 : 4WD SWITCH
 - ASC OFF SWITCH
 - DOWNLIGHT
 - ELECTRIC TAILGATE SWITCH
 - FCM SWITCH
 - HEADLAMP MANUAL LEVELLING SWITCH
 - HEATED SEAT SWITCH
 - LDW SWITCH
 - METER INFORMATION SWITCH
 - S-AWC DRIVE
 - MODE-SELECTOR
 - SONAR SWITCH



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige