



- NOTE
- * 1 : .ABS-ECU
 - .ACC/FCM-ECU
 - .ASC-ECU
 - .A/T CONTROL RELAY
 - .COLUMN SWITCH
 - .COMBINATION METER
 - .CVT-ECU
 - .EPS-ECU
 - .HAZARD INDICATOR ASSEMBLY
 - .HEATED SEAT RELAY
 - .HEATER CONTROLLER ASSEMBLY (A/C-ECU)
 - .LDW-ECU
 - .PRIMARY PULLEY SPEED SENSOR
 - .PTC HEATER RELAY
 - .SECONDARY PULLEY SPEED SENSOR
 - .STEERING WHEEL SENSOR
 - .SUNROOF MOTOR ASSEMBLY
 - .TURBINE SPEED SENSOR
 - .WATER LEVEL SWITCH

Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige

HHU11X04CC