



- .ABS-ECU
- .ACC/FCM-ECU
- .ASC-ECU
- .A/T CONTROL RELAY
- .COLUMN SWITCH
- .COMBINATION METER
- .CORNER SENSOR/BACK SENSOR-ECU
- .CVT-ECU
- .EPS-ECU
- .HAZARD INDICATOR ASSEMBLY
- .HEATED SEAT RELAY
- .KOS-ECU
- .LDW-ECU
- .PRIMARY PULLEY SPEED SENSOR
- .SECONDARY PULLEY SPEED SENSOR
- .SELECTOR LEVER ASSEMBLY
- .SONAR SWITCH
- .STEERING WHEEL SENSOR
- .SUNROOF MOTOR ASSEMBLY
- .TURBINE SPEED SENSOR

NOTE
 *1 : VEHICLES WITHOUT KOS
 *2 : VEHICLES WITH KOS



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige