



- NOTE
- \*1: LHD
  - \*2: RHD
  - \*3: VEHICLES WITHOUT KOS
  - \*4: VEHICLES WITH KOS
  - \*5:
    - ABS-ECU
    - ACC/FCM-ECU
    - ASC-ECU
    - A/T CONTROL RELAY
    - COMBINATION METER
    - CORNER SENSOR/BACK SENSOR-ECU
    - CVT-ECU
    - EPS-ECU
    - HAZARD INDICATOR ASSEMBLY
    - HEATED SEAT RELAY
    - HEATER CONTROLLER ASSEMBLY (A/C-ECU)
    - KOS-ECU
    - LDW-ECU
    - PTC HEATER RELAY
    - PRIMARY PULLEY SPEED SENSOR
    - SECONDARY PULLEY SPEED SENSOR
    - SELECTOR LEVER ASSEMBLY
    - SONAR SWITCH
    - STEERING WHEEL SENSOR
    - SUNROOF MOTOR ASSEMBLY
    - TURBINE SPEED SENSOR
    - WATER LEVEL SWITCH

