



- NOTE
- \*1: .ABS-ECU
  - .ACC/FCM-ECU
  - .ASC-ECU
  - .AT CONTROL RELAY
  - .COLUMN SWITCH
  - .COMBINATION METER
  - .CVT-ECU
  - .EPS-ECU
  - .HAZARD INDICATOR ASSEMBLY
  - .HEATED SEAT RELAY
  - .HEATER CONTROLLER ASSEMBLY (A/C-ECU)
  - .LDW-ECU
  - .PRIMARY PULLEY SPEED SENSOR
  - .PTC HEATER RELAY
  - .SECONDARY PULLEY SPEED SENSOR
  - .STEERING WHEEL SENSOR
  - .SUNROOF MOTOR ASSEMBLY
  - .TURBINE SPEED SENSOR
  - .WATER LEVEL SWITCH
- \*2: EXCEPT VEHICLES FOR BRAZIL  
\*3: VEHICLES FOR BRAZIL



Wire colour code  
 B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown  
 O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver BE: Beige