



- ABS-ECU
- ASC-ECU
- COLUMN SWITCH
- CORNER SENSOR/BACK SENSOR-ECU
- CVT-ECU
- EPS-ECU
- HAZARD INDICATOR ASSEMBLY
- HEATED SEAT RELAY
- HEATER CONTROLLER ASSEMBLY (A/C-ECU)
- KOS-ECU
- PRIMARY PULLEY SPEED SENSOR
- SECONDARY PULLEY SPEED SENSOR
- SELECTOR LEVER ASSEMBLY
- SONAR SWITCH
- STEERING WHEEL SENSOR
- SUNROOF MOTOR ASSEMBLY
- TURBINE SPEED SENSOR

NOTE  
\*1 : VEHICLES WITHOUT KOS  
\*2 : VEHICLES WITH KOS


**ELECTRONIC CONTROL COUPLING SOLENOID (D-116)**



- ASC OFF SWITCH
- DOWNLIGHT
- ELECTRIC TAILGATE SWITCH
- HAZARD INDICATOR ASSEMBLY
- HEADLAMP MANUAL LEVELLING SWITCH
- HEATED SEAT SWITCH
- METER INFORMATION SWITCH
- RADIO AND CD PLAYER
- SONAR SWITCH
- SPARE CONNECTOR (FOR AUDIO)



- ASC OFF SWITCH
- DOWNLIGHT
- ELECTRIC TAILGATE SWITCH
- HAZARD INDICATOR ASSEMBLY
- HEADLAMP MANUAL LEVELLING SWITCH
- HEATED SEAT SWITCH
- METER INFORMATION SWITCH
- SONAR SWITCH



Wire colour code  
B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown  
O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige