

Apply engine oil to the timing chain and its contact surfaces for installation.

