



No. 3 exhaust gas temperature sensor

The diagram shows a top-down view of an engine compartment. A sensor is mounted on the exhaust manifold, with a wiring harness leading to the right. A transmission is located at the bottom center of the engine. Various hoses and components are visible throughout the engine bay.

Transmission

ACE01905AB