




-  : The selector lever moves when the brake pedal is depressed and the button is pushed in with the ignition key in any position other than the LOCK (OFF) position.
-  : The selector lever moves without pushing the button.
-  : The selector lever moves when the button is pushed.