





<LHD>




<RHD>



 : The selector lever moves when the brake pedal is depressed and the button is pushed in with the ignition switch at ON position.

 : The selector lever moves without pushing the button.

 : The selector lever moves when the button is pushed.