


<Incorrect  
state>



Oil seal lip  
protruded

The diagram shows a cross-section of a mechanical assembly. A cylindrical component is mounted on a shaft. An oil seal is installed around the shaft. The oil seal lip is shown protruding outwards from the housing, which is an incorrect state. A leader line points from the text 'Oil seal lip protruded' to the protruding lip. Another leader line points from the text '<Incorrect state>' to the entire assembly area.

**AC510591AB**