




AC500631



Grease:
Repair kit grease:
 125 ± 10 g (Joint: 55 g, Boot: 70 g)
Note
 The grease in the repair kit should be divided in half for use, respectively, at the joint and inside the boot.

AC501588AC



Grease: Repair kit grease

Grease:
Repair kit grease: 125 ± 10 g (joint: 80 g, boot: 45 g)
Note
 The grease in the repair kit should be divided in half for use, respectively, at the joint and inside the boot.

CAUTION

Do not mix old and new or different types of grease, as a special grease is used in the joint.