Memory Initialization Delete all backup data stored within the Navi, (histories, learning data, Address Books, etc.) and reset to factory defaults. After reset, restart the system. [Start] memory initialization?