


**A** <4WD>



The diagram shows the interior of a vehicle, specifically the area around the driver's seat and the battery. A spare connector for a trailer is shown in the lower-left area, with a black arrow pointing to it. The battery is located in the upper-right area, with a line pointing to it. The text 'A <4WD>' is in the top-left corner, and 'ACE02840AC' is in the bottom-right corner.

**Spare connector  
(for trailer)**

**Battery**

**ACE02840AC**