


- NOTE
- \*1 : CAMERA-ECU  
CENTRE ROOM LAMP  
COLUMN SWITCH  
COMBINATION METER  
DOOR COURTESY LAMP  
GATEWAY-ECU  
LUGGAGE COMPARTMENT LAMP  
PERSONAL LAMP  
VANITY MIRROR LAMP
  - \*2 : A/C-ECU  
AIR REFRESHER IONIZER SWITCH  
ASC OFF SWITCH  
BLIND SPOT WARNING SWITCH  
COMBINATION METER  
FORWARD COLLISION MITIGATION SYSTEM (FCM) AND ULTRASONIC MISACCELERATION MITIGATION SYSTEM ON/OFF SWITCH  
GLOVE BOX LAMP  
HAZARD INDICATOR ASSEMBLY  
HAZARD WARNING LAMP SWITCH  
HEADLAMP MANUAL LEVELLING SWITCH  
HEATED SEAT SWITCH (FRONT)  
MULTIVISION DISPLAY  
RADIO AND CD PLAYER
  - \*3 : DRIVE MODE- SELECTOR  
HILL DESCENT CONTROL SWITCH  
OFF-ROAD MODE SELECTOR  
REAR COOLER CONTROL PANEL  
SPOT LAMP
  - \*4 : DRIVE MODE-SELECTOR  
HILL DESCENT CONTROL SWITCH  
OFF-ROAD MODE SELECTOR

- A/C-ECU
- BLIND SPOT WARNING SWITCH
- CLEARANCE WARNING CONTROL UNIT
- COLUMN SWITCH (STEERING WHEEL SENSOR)
- ETACS-ECU
- GATEWAY-ECU
- HAZARD INDICATOR ASSEMBLY
- SELECTOR LEVER ASSEMBLY (SHIFT LOCK SOLENOID, SHIFT SWITCH)
- SONAR SWITCH
- TRANSFER-ECU



Wire colour code  
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown  
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige