



FUSIBLE LINK ⑤
2

NOTE
*1 : 4G6
*2 : 6B3



- ENGINE CONTROL RELAY (A-207X)
- AIR FLOW SENSOR
 - CAMSHAFT POSITION SENSOR*1, 2
 - CRANK ANGLE SENSOR*1, 2
 - EGR COOLER BYPASS CONTROL SOLENOID VALVE
 - ENGINE-ECU
 - EXHAUST GAS RECIRCULATION VALVE *2
 - FRONT OXYGEN SENSOR
 - GLOW CONTROL UNIT
 - LEFT BANK OXYGEN SENSOR (FRONT, REAR)
 - NO.1 TO NO.4 INJECTOR *1
 - NO.1 TO NO.6 INJECTOR*2
 - OIL FEEDER CONTROL VALVE
 - PURGE CONTROL SOLENOID VALVE
 - REAR OXYGEN SENSOR
 - RIGHT BANK OXYGEN SENSOR (FRONT, REAR)
 - THROTTLE VALVE CONTROL SERVO RELAY
 - VARIABLE GEOMETRY CONTROL SOLENOID VALVE



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige