


- .4WD INDICATOR-ECU
- .A/C-ECU
- .BLIND SPOT WARNING SWITCH
- .CLEARANCE WARNING CONTROL UNIT
- .COLUMN SWITCH
- .COLUMN SWITCH (STEERING WHEEL SENSOR)
- .COMBINATION METER
- .E-CALL CONTROL UNIT
- .E-CALL RELAY BOX
- .ELECTRIC PARKING BRAKE
- .GATEWAY-ECU
- .HAZARD INDICATOR ASSEMBLY
- .HEATED STEERING WHEEL SWITCH
- .SELECTOR LEVER ASSEMBLY (SHIFT LOCK SOLENOID, SHIFT SWITCH)
- .SONAR SWITCH
- .TRANSFER-ECU

NOTE
 *1 : LHD
 *2 : RHD



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige