


IGNITION SWITCH (IG1) OR IG1 RELAY




FUSIBLE LINK ②

<4G6>



- A/C-ECU
- BLIND SPOT WARNING SWITCH
- CLEARANCE WARNING CONTROL UNIT
- COLUMN SWITCH
- COLUMN SWITCH (STEERING WHEEL SENSOR)
- COMBINATION METER
- ELECTRIC PARKING BRAKE
- GATEWAY-ECU
- SELECTOR LEVER ASSEMBLY (SHIFT LOCK SOLENOID, SHIFT SWITCH)
- SONAR SWITCH
- TRANSFER-ECU

- A/C-ECU
- CAMERA-ECU
- CENTRE ROOM LAMP
- COLUMN SWITCH
- DOOR COURTESY LAMP
- ELECTRIC PARKING BRAKE SWITCH
- GATEWAY-ECU
- KEY REMINDER SWITCH (ILL)
- KOS&OSS-ECU
- LUGGAGE COMPARTMENT LAMP
- MULTIVISION DISPLAY
- RADIO AND CD PLAYER



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige