



NOTE
 *3 : VEHICLES WITHOUT ASTC
 *4 : VEHICLES WITH ASTC

- 4WD INDICATOR-ECU
- A/C-ECU
- BLIND SPOT WARNING SWITCH
- CLEARANCE WARNING CONTROL UNIT
- COLUMN SWITCH
- COLUMN SWITCH (STEERING WHEEL SENSOR)
- E-CALL CONTROL UNIT
- E-CALL RELAY BOX
- ELECTRIC PARKING BRAKE
- ETACS-ECU
- GATEWAY-ECU
- HAZARD INDICATOR ASSEMBLY
- HEATED STEERING WHEEL SWITCH
- SELECTOR LEVER ASSEMBLY (SHIFT LOCK SOLENOID, SHIFT SWITCH)
- SONAR SWITCH
- TRANSFER-ECU

