



- NOTE**
- *1: CAMERA-ECU, CENTRE ROOM LAMP, COLUMN SWITCH, COMBINATION METER, DOOR COURTESY LAMP, GATEWAY-ECU, LUGGAGE COMPARTMENT LAMP, MULTIVISION DISPLAY, PERSONAL LAMP, RADIO AND CD PLAYER, SMARTPHONE LINK DISPLAY AUDIO
 - *2: A/C-ECU, ASC OFF SWITCH, BLIND SPOT WARNING SWITCH, COMBINATION METER, E-CALL SWITCH, FORWARD COLLISION MITIGATION SYSTEM (FCM) AND ULTRASONIC MISACCELERATION MITIGATION SYSTEM, ON/OFF SWITCH, GLOVE BOX LAMP, HAZARD INDICATOR ASSEMBLY, HAZARD WARNING LAMP SWITCH, HEADLAMP MANUAL LEVELLING SWITCH, HEATED SEAT SWITCH (FRONT), HEATED STEERING WHEEL SWITCH, MULTIVISION DISPLAY, RADIO AND CD PLAYER, REAR DIFFERENTIAL LOCK SWITCH, REAR DISPLAY UNIT, REAR FAN SWITCH, SELECTOR LEVER ASSEMBLY, SMARTPHONE LINK DISPLAY AUDIO, SONAR SWITCH, STEERING WHEEL REMOTE CONTROL SWITCH
 - *3: DRIVE MODE-SELECTOR, HEATED SEAT SWITCH (SECOND), HILL DESCENT CONTROL SWITCH, OFF-ROAD MODE SELECTOR, REAR COOLER CONTROL PANEL
 - *4: DRIVE MODE-SELECTOR, HEATED SEAT SWITCH (SECOND), HILL DESCENT CONTROL SWITCH, OFF-ROAD MODE SELECTOR

- CLEARANCE WARNING CONTROL UNIT
- COLUMN SWITCH (STEERING WHEEL SENSOR)
- E-CALL CONTROL UNIT
- ETACS-ECU
- GATEWAY-ECU
- HAZARD INDICATOR ASSEMBLY
- SELECTOR LEVER ASSEMBLY (SHIFT LOCK SOLENOID, SHIFT SWITCH)
- SONAR SWITCH
- TRANSFER-ECU

Terminal Blocks:

- (A-215) 12-pin connector
- (D-25) 22-pin connector
- (D-113) 22-pin connector
- (D-116) 18-pin connector
- (D-118) 22-pin connector
- (D-216) 4-pin connector
- (D-244) 22-pin connector
- (D-255) 18-pin connector
- (D-256) 18-pin connector
- (D-402) 6-pin connector
- (D-405) 8-pin connector
- (D-409) 7-pin connector
- (E-105) 12-pin connector
- (E-105-1) 2-pin connector
- (E-105-2) 26-pin connector
- (E-120) 6-pin connector

Wire colour code:
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige