




Apply engine oil to all moving parts before installation.



<M/T-Except high power engine>



<M/T-High power engine>



<A/T>

