

Checking Sensor

**Change the direction of travel,
and travel 10m or more.**