



RVC

RVC Setting

1. Choose the Camera Functions

OFF

ON

2. Choose the Guidelines displays

OFF

ON

3. Choose the type of vehicle



DONE