

Heater air control damper
(Mode selection damper)

Heater case

Heater air control damper
(Outside/Inside air selection damper)

Heater air intake case

Heater air control damper
(Air mixing damper control motor)

Fin thermo sensor
<Vehicles with manual A/C>

A/C temperature
control resistor

Blower motor

