








- A/C-ECU
- COLUMN SWITCH
- ETACS-ECU
- HAZARD INDICATOR ASSEMBLY
- INDICATOR ASSEMBLY
- SELECTOR LEVER ASSEMBLY
- STEERING WHEEL SENSOR
- TRANSFER-ECU



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige