


- NOTE
- *1: .CLOCK
.COLUMN SWITCH
.COMBINATION METER
.HANDS FREE-ECU
.KEY REMINDER SWITCH
.KOS&OSS-ECU
.RADIO AND CD PLAYER
.SPARE CONNECTOR (FOR AUDIO)
 - *2: .CLOCK
.COMBINATION METER
.CRUISE CONTROL SWITCH
.DRIVE MODE-SELECTOR
.GLOVE BOX LAMP
.HAZARD WARNING LAMP SWITCH
.HEADLAMP MANUAL LEVELLING SWITCH
.RADIO AND CD PLAYER
.SELECTOR LEVER ASSEMBLY
.SPARE CONNECTOR (FOR AUDIO)
.STEERING WHEEL MULTI-FUNCTION SWITCH

- .COLUMN SWITCH
- .COMBINATION METER
- .ETACS-ECU
- .SELECTOR LEVER ASSEMBLY
- .TRANSFER-ECU



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige