


- NOTE
- \*1 : .CLOCK  
.COLUMN SWITCH  
.COMBINATION METER  
.DAB TUNER  
.HANDS FREE-ECU  
.KEY REMINDER SWITCH  
.KOS&OSS-ECU  
.MULTIVISION DISPLAY  
.RADIO AND CD PLAYER  
.SPARE CONNECTOR (FOR AUDIO)
  - \*2 : .ASC OFF SWITCH  
.CLOCK  
.COMBINATION METER  
.CRUISE CONTROL SWITCH  
.DRIVE MODE-SELECTOR  
.GLOVE BOX LAMP  
.HAZARD INDICATOR ASSEMBLY  
.HAZARD WARNING LAMP SWITCH  
.HEADLAMP MANUAL LEVELLING SWITCH  
.MULTIVISION DISPLAY  
.RADIO AND CD PLAYER  
.REAR DIFFERENTIAL LOCK SWITCH  
.SELECTOR LEVER ASSEMBLY  
.SPARE CONNECTOR (FOR AUDIO)  
.STEERING WHEEL MULTI-FUNCTION SWITCH

- .COLUMN SWITCH
- .COMBINATION METER
- .ETACS-ECU
- .HAZARD INDICATOR ASSEMBLY
- .SELECTOR LEVER ASSEMBLY
- .STEERING WHEEL SENSOR
- .TRANSFER-ECU



Wire colour code  
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown  
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige