



NOTE

- *3 : 4G6
- *4 : 4D5, 4N1
- *5 : <4G6>
- AIR FLOW SENSOR
- CAMSHAFT POSITION SENSOR
- CRANK ANGLE SENSOR
- FRONT OXYGEN SENSOR
- NO.1 TO NO.4 INJECTOR
- PURGE CONTROL SOLENOID VALVE
- REAR OXYGEN SENSOR
- THROTTLE VALVE
- CONTROL SERVO RELAY
- VEHICLE SPEED SENSOR

<4D5>

- AIR FLOW SENSOR
- GLOW PLUG RELAY
- THROTTLE SOLENOID VALVE
- VARIABLE GEOMETRY CONTROL SOLENOID VALVE
- VEHICLE SPEED SENSOR

<4N1>

- AIR FLOW SENSOR
- EGR COOLER BYPASS CONTROL SOLENOID VALVE
- GLOW PLUG RELAY
- OIL FEEDER CONTROL UNIT
- VARIABLE GEOMETRY CONTROL SOLENOID VALVE

