


- A/C-ECU
- COLUMN SWITCH
- COMBINATION METER
- HAZARD INDICATOR ASSEMBLY
- SELECTOR LEVER ASSEMBLY
- STEERING WHEEL SENSOR
- TRANSFER-ECU

NOTE

- *1: 4G6
- *2: 4D5, 4N1
- *3: <4G6>
- AIR FLOW SENSOR
- CAMSHAFT POSITION SENSOR
- CRANK ANGLE SENSOR
- FRONT OXYGEN SENSOR
- NO.1 TO NO.4 INJECTOR
- PURGE CONTROL SOLENOID VALVE
- REAR OXYGEN SENSOR
- THROTTLE VALVE CONTROL SERVO RELAY
- VEHICLE SPEED SENSOR
- AIR FLOW SENSOR
- GLOW PLUG RELAY
- THROTTLE SOLENOID VALVE
- VARIABLE GEOMETRY CONTROL SOLENOID VALVE
- GLOW PLUG RELAY
- OIL FEEDER CONTROL UNIT
- VARIABLE GEOMETRY CONTROL SOLENOID VALVE



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White
 Y : Yellow SB : Sky blue BR : Brown O : Orange GR : Grey
 R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige