


- NOTE
- *1 : A/C-ECU
 .COLUMN SWITCH
 .ETACS-ECU
 .SELECTOR LEVER ASSEMBLY
 .STEERING WHEEL SENSOR
 .TRANSFER-ECU
 - *2 : A/C-ECU
 .ASC OFF SWITCH
 .CLOCK
 .COMBINATION METER SWITCH
 .CRUISE CONTROL SWITCH
 .DRIVE MODE-SELECTOR
 .GLOVE BOX LAMP
 .HAZARD WARNING LAMP SWITCH
 .HEADLAMP MANUAL LEVELLING SWITCH
 .HEATER CONTROLLER ASSEMBLY
 .MULTIVISION DISPLAY
 .RADIO AND CD PLAYER
 .REAR DIFFERENTIAL LOCK SWITCH
 .SELECTOR LEVER ASSEMBLY
 .SPARE CONNECTOR (FOR AUDIO)
 .STEERING WHEEL MULTI-FUNCTION SWITCH



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver BE : Beige