FUSIBLE LINK ②
1 A
8L
1 (C-408)

FUSIBLE LINK (SBF3)
3 C
3W
7 (C-406)

J/B

⑤ ⑥ ⑪ 10A ⑫ 15A ⑰ ⑱ 10A ㉒ 30A ㉓ 30A ㉔ ㉖ 15A

·DIAGNOSIS CONNECTOR
·ETACS-ECU (DOOR LOCK /UNLOCK RELAY)

REAR FOG LAMP RELAY

BLOWER RELAY

⑬ 15A

·AUTO A/C CONTROLLER ASSEMBLY (A/C-ECU)
·COLUMN SWITCH
·FRONT ROOM LAMP
·KOS AND OSS-ECU
·RADIO AND CD PLAYER

5 6 M

ETACS-ECU (C-407)

20 (ETACS +B)

16 (TAIL +B)

POWER SOURCE

OFF ON

TAIL LAMP RELAY

(TAIL LP)

15

① 7.5A

⑦ 7.5A

·LICENCE PLATE LAMP
·POSITION LAMP (LH)
·REAR COMBINATION LAMP (TAIL:LH)

·AUTO A/C CONTROLLER ASSEMBLY (A/C-ECU)
·COMBINATION METER
·HAZARD WARNING LAMP SWITCH
·HEATER CONTROL PANEL
·POSITION LAMP (RH)
·RADIO AND CD PLAYER
·REAR COMBINATION LAMP (TAIL:RH)

FUSE ⑯
7 L

1 4

REAR WINDOW DEFOGGER RELAY (C-412)

ON OFF

2 3

⑲ 7.5A

ETACS-ECU

REAR WINDOW DEFOGGER

·AUTO A/C CONTROLLER ASSEMBLY (A/C-ECU)
·HEATER CONTROL PANEL

(C-406) MU801867



(C-407) J/B SIDE



(C-408) MU801401

(C-412)

Wire colour code
B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver

ACE00832AB